



Owner's Manual

BP-9-SP Shotblasting Machine



BLASTPRO MANUFACTURING, INC. ~ WARRANTY & REGISTRATION CARD
ONE YEAR LIMITED WARRANTY
(1-877-495-6464)

A COPY OF THE WARRANTY CARD ON THE FOLLOWING PAGE, TOGETHER WITH PROOF OF PAYMENT, MUST BE SUBMITTED WITH ANY SERVICE REQUEST. THIS WARRANTY CARD MUST BE RETURNED TO: BLASTPRO MANUFACTURING, INC., 6021 MELROSE LANE, OKLAHOMA CITY, OK 73127, WITHIN TEN (10) DAYS OF ACQUIRING BLASTPRO PRODUCTS IN ORDER TO QUALIFY FOR THE ONE YEAR LIMITED WARRANTY CONTAINED IN THE SALES AGREEMENT.

BlastPro provides as a limited warranty to Original Purchasers of BlastPro equipment, purchased within and situated within the United States of America, who notify BlastPro in writing through completion of the BlastPro Equipment Warranty Card within ten (10) days of acquiring BlastPro Equipment, the following limited warranty.

Subject to the exclusions, limitations and conditions stated above and below, BlastPro will warrant its products against defects in materials and workmanship, provided the Original Purchaser uses such equipment under normal and proper use, for a period of one year or 1,000 hours, whichever occurs first, from the date of delivery to the Original Purchaser.

During the applicable limited warranty period and subject to the exclusions, limitations and conditions contained herein, BlastPro shall, within a reasonable period of time, repair or replace, at its option, any defective components of the equipment. The limited warranty does not cover wear parts, including but not limited to, tires, magnets, seals, casters, liners, wear plates, bearings, cages, blast wheels, blades, belts, electrical wiring components and items of a similar nature.

This limited warranty does not cover damage to BlastPro equipment caused by any of the following: the use of the equipment for purposes other than which the equipment was designed and intended, all external causes such as (without limitation) acts of God, accidents, dropping, collision, fire, water damage, freezing, striking other objects, misuse or otherwise using the equipment contrary to the instructions and warnings contained in the User Manual; altering or modifying BlastPro equipment or accessories; exposure to environmental conditions beyond reasonable limits and the limits stated in the equipment manual; failure to properly maintain and service the equipment; damage caused by the use of any non-BlastPro parts or attachments on the equipment.

To obtain repair or replacement under this limited warranty, the Original Purchaser must contact BlastPro at 1-877-495-6464. The Original Purchaser must be prepared to describe any alleged problem, as well as provide proof of purchase and proof of date of delivery and return of the Equipment Warranty Card. Written authorization from BlastPro must be obtained prior to any BlastPro equipment being returned to BlastPro.

Once BlastPro provides the Original Purchaser with a written authorization, then the Original Purchaser shall deliver the equipment as instructed by BlastPro. The Original Purchaser shall pay the cost of shipping and shall also bear any risk of loss during shipping. Providing the BlastPro equipment is defective and the limited warranty applies, BlastPro shall, within a reasonable period of time, repair or replace any defective components. The Original Purchaser shall be responsible for picking up the repaired equipment or may arrange for shipment at Original Purchaser's expense.

BlastPro's repair or replacement of any defective parts on the equipment does not extend the term of this limited warranty, which shall expire on expiration of the period of one year from the date of Original delivery, subject to the further terms of this warranty.

THIS LIMITED WARRANTY IS THE ONLY WARRANTY APPLICABLE TO BLASTPRO EQUIPMENT. BLASTPRO DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE WARRANTIES IMPLIED AND INCAPABLE OF EXCLUSION, RESTRICTION OR MODIFICATION UNDER APPLICABLE LAW. ANY SUCH IMPLIED WARRANTIES WHICH MAY BE REQUIRED BY LAW AND ARE NOT DISCLAIMED HEREBY, ARE LIMITED TO THE EXTENT ALLOWED BY LAW TO THE APPLICABLE PERIOD OF THIS IMPLIED WARRANTY OR TO THE APPLICABLE TIME PERIOD PROVIDED BY THE APPLICABLE STATE LAW, WHICHEVER PERIOD IS SHORTER.

UNDER NO CIRCUMSTANCES SHALL BLASTPRO BE LIABLE TO THE ORIGINAL PURCHASER OR ANY OTHER PERSON FOR ANY DIRECT, INDIRECT OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR MISUSE OF THE EQUIPMENT OR ARISING OUT OF ANY BREACH OF ANY WARRANTY OR FOR ANY SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY CHARACTER, INCLUDING WITHOUT LIMITATION, DAMAGES FOR ANY LOSS OF GOODWILL, WORK STOPPAGE OR ANY AND ALL OTHER COMMERCIAL DAMAGES OR LOSSES.

NO CHANGE TO OR ADDITIONAL WARRANTY, NO MATTER BY WHOM MADE OR WHEN MADE, SHALL APPLY TO ANY EQUIPMENT SOLD BY BLASTPRO.

BlastPro Warranty Registration Card

NOTICE!

To ensure the proper warranty coverage is extended to the owner of this machine, fill out the attached card **COMPLETELY** and **ACCURATELY** and return to BlasPro Mfg.

Keep this top portion for your records

USER'S REFERENCE INFORMATION

Delivery Date _____

Machine Model No. _____

Delivering Distributors Name
and Address _____

Machine Serial No. _____

Modifications _____

CUT HERE

WARRANTY REGISTRATION CARD

IMPORTANT! To ensure that your BlastPro machine is covered under warranty, please fill in the following information and mail it to BlastPro Manufacturing, Inc.
6021 Melrose Lane, Oklahoma City, OK 73127, or Fax to 405-495-1331

(All boxes must be checked or date filled in)

Operating Manual Received

☐

Training Scheduled _____

Training Complete

☐

(Please Print)

Company _____

Address _____

City _____ State _____ Zip _____

Phone Number _____

Contact Person _____

Purchase Date _____ Delivery Date _____

Machine Model No. _____

Distributor Name _____



DANGER



Respirable crystalline silica
May cause cancer
Causes damage to lungs



Insure compliance with
OSHA 29 CFR §1926.1153

BP-9-SP Table of Contents

FORWARD	2
INTRODUCTION	3
SPECIFICATIONS:	3
SAFETY INSTRUCTIONS	4
SAFETY — GENERAL.....	4
SAFETY — SITE ASSESSMENT PROCEDURES	4
SAFETY—START UP PROCEDURES	6
SAFETY — OPERATION PROCEDURES.....	7
SAFETY — SHUT DOWN PROCEDURES	8
SAFETY — MAINTENANCE PROCEDURES	8
CHECK LIST.....	10
OPERATING INSTRUCTIONS—START UP	11
SETTING THE BLAST PATTERN.....	12
<i>Proper Control Cage Setting Drawing</i>	13
OPERATING INSTRUCTIONS—SHUT DOWN	14
OPERATION ADJUSTMENTS	15
BLAST HOUSING HEIGHT.....	15
CONTROL CAGE SETTING	15
SHOT SELECTION RECOMMENDATIONS	15
TRAVEL SPEED SUGGESTIONS	15
EXHAUST HOSE LENGTH	15
TRANSPORTATION.....	16
DUST COLLECTOR FUNCTION.....	17
DUST COLLECTOR MAINTENANCE	17
<i>Filter Cartridge Removal</i>	17
WEAR PARTS.....	18
MAINTENANCE.....	19
BLAST WHEEL REMOVAL AND INSTALLATION	19
LUBRICATION	19
SHOT BLASTING PROBLEMS & POSSIBLE SOLUTIONS	20

Forward

Thank you for your purchase of a shot blasting machine from BlastPro Manufacturing, Inc. We feel that you have purchased the highest quality shot blasting equipment on the market today.

This manual has been prepared to give the operator a general understanding of the machine. It is not intended to be an all encompassing document which addresses every situation which may be encountered when operating the machine. **BEFORE OPERATING, MAINTAINING, AND/OR SERVICING THE EQUIPMENT, THIS MANUAL SHOULD BE READ BY THE INDIVIDUALS RESPONSIBLE FOR THE OPERATION, MAINTENANCE, AND/OR SERVICE OF THE EQUIPMENT.**

The individuals responsible for operating, maintaining, and servicing the equipment should thoroughly understand and follow all safety precautions listed on the equipment and the safety instructions listed in this manual. As with any piece of construction equipment, serious damage to the equipment and serious injury to people can occur if the safety instructions and safety warnings are not followed.

If you have any questions or problems regarding the operation of the equipment, then please call:

BlastPro Manufacturing, Inc.
6021 Melrose Lane
Oklahoma City, OK 73127
Toll free: 877-495-6464
Phone: 405-491-6464
Fax: 405-495-4994
Website: www.BlastProMfg.com

Introduction

The BP-9-SP is an affordable self-propelled 230 volt single phase blast cleaning system designed for small to medium sized jobs as well as for acting as a complimentary unit on larger jobs. Ideal for edge work and hard-to-reach areas, the BP-9-SP is utilized to prepare concrete surfaces prior to the application of paint, coatings, or overlays on areas such as garage floors, balconies, basements, pool decks, and edges.

The mechanics of the BP-9-SP are fairly simple. Shot from the blast wheel, which sits in a control cage, is thrown over 200 mph through an opening in the control cage and down onto to the concrete surface that is being cleaned. Due to the high rate of speed at which the shot is traveling, it acts to fracture the underlying surface which consequently produces concrete dust. After hitting the concrete surface, the shot rebounds off of it and, through a combination of the rebound effect and the use of a vacuum, the shot as well as the concrete dust move through the blast housing. Because shot is heavier than concrete dust, gravitational force causes the shot to be sent back into the shot hopper where it is continuously recycled by the machine. As for the concrete dust, it is sucked into a duct hose which travels from the blast housing to the dust collector. After traveling through the duct hose, the concrete dust is deposited in the dust collector's dust bin.

Specific advantages of the BP-9-SP include that fact that it as well as all of its parts are made in the United States. As a result, there is typically no lead time when ordering parts. Also, the electrical box and electrical components of the BP-9-SP are engineered and constructed by a UL certified electrical contractor. The type W 12/3 electrical cord used in the BP-9-SP is the toughest and most wear-resistant cord available on the market today. Finally, twenty-four hour customer service comes standard with the purchase of a BP-9-SP machine.

Specifications:

Production Capacity.....	450 sq. ft./hr.
Blast Pattern.....	9"
Travel Speed	2-80 ft./min.
Blast Motor	4 h.p.
Voltage.....	230 volt single phase
Amperage.....	17 amps
Minimum Generator.....	15 kw
Dimensions	36" x 12" x 48"
Weight.....	318 lbs.
Power Cord Length.....	50 ft.
Seals	Magnetic/Brushes
Distance to Edge	1.5"
Dust Collector	Required

Safety Instructions

ALL OPERATORS AND MAINTENANCE PERSONNEL SHOULD READ THIS SECTION CAREFULLY BEFORE OPERATING OR MAINTAINING THIS MACHINE. THESE SAFETY INSTRUCTIONS ARE NOT MEANT TO REPRESENT AN ALL INCLUSIVE LIST OF INSTANCES WHICH COULD OCCUR WHEN OPERATING THIS MACHINE. FOR, AS WITH ANY PIECE OF CONSTRUCTION EQUIPMENT, SERIOUS INJURY CAN OCCUR IF PROPER SAFETY PROCEDURES ARE NOT DILIGENTLY FOLLOWED. ALL SAFETY AND WARNING LABELS POSTED ON THE MACHINE MUST BE FOLLOWED AS WELL AS THE SAFETY PROGRAM INSTITUTED BY YOUR COMPANY. THERE IS NO SUBSTITUTE FOR GOOD JUDGEMENT IN THE OPERATION AND MAINTENANCE OF THIS EQUIPMENT. IN CASES WHERE OPERATING PERSONNEL HAVE INSUFFICIENT KNOWLEDGE OR UNDERSTANDING OF THE ENGLISH LANGUAGE, PROPER TRANSLATED TRAINING MUST BE COMPLETED BEFORE USE OF THIS EQUIPMENT CAN TAKE PLACE.

Note: This manual must be kept with the machine at all times so as to allow the operator easy access to its vital information.

Safety — General

The United States Department of Labor's Occupational Safety & Health Administration (OSHA) provides statutory requirements, standards, and regulations relating to the use of portable tools on construction sites. These statutory requirements, standards, and regulations are posted on the OSHA website at www.osha.gov. The operator and maintenance personnel should understand and follow these statutory requirements, standards, and regulations.

Safety — Site Assessment Procedures

Before starting blasting operations, a site assessment must be performed. During the site assessment verify the following:

- Work area is flat, clean, and dry, free of debris, frost-free, and has no flammable liquids nearby. Also, make sure that the machine will be able to clear all obstructions. **NEVER BLAST A WET FLOOR. NEVER BLAST OVER BOLTS, NUTS, SCREWS, NAILS, OR OTHER DEBRIS AS THIS MAY RESULT IN SIGNIFICANT DAMAGE TO THE MACHINE AND SERIOUS INJURY TO THE OPERATOR.**
- If using a generator, then proper safety precautions have been undertaken in order to help reduce the risk of carbon monoxide poisoning. For further information, refer to the owner's manual of your generator.
- Operator and any other personnel in the work area are wearing safety glasses with side shields, dust masks, ear plugs, hard hats, steel-toed work boots, long sleeved shirts, tight fitting clothing, and gloves. It is also imperative for staff to tie back long hair and to remove all jewelry.
- **FLOORS HAVE BEEN THOROUGHLY INSPECTED. SOME FLOOR OR DECK SURFACES MAY BE COATED WITH OR CONTAMINATED BY DANGEROUS**

MATERIALS SUCH AS PCBs, LEAD, ASBESTOS, PESTICIDES, SOLVENTS, CLEANING FLUIDS, AND/OR OTHER HARMFUL CHEMICALS. THE DUST PRODUCED FROM SHOT BLASTING SUCH SURFACES CAN CREATE A SERIOUS HEALTH THREAT TO THOSE WHO INHALE OR COME INTO CONTACT WITH THE DUST. AS A RESULT, THE WORK AREA MUST BE CHECKED FOR THESE MATERIALS BEFORE WORK CAN BEGIN. BLASTPRO MANUFACTURING, INC. DOES NOT WARRANT ITS EQUIPMENT TO BE SUITABLE FOR, OR APPROVED FOR, REMOVING DANGEROUS MATERIALS. IT IS, THEREFORE, THE RESPONSIBILITY OF THE CONTRACTOR TO AFFIRM THE SAFETY OF THE WORK AREA AND THE EQUIPMENT WITH THE PROPER AUTHORITIES. IT IS ALSO THE RESPONSIBILITY OF THE CONTRACTOR TO WARN ALL STAFF MEMBERS OF ALL OF THE POTENTIAL SHORT-TERM AND LONG-TERM HEALTH RISKS ASSOCIATED WITH INHALING AND COMING INTO CONTACT WITH DANGEROUS MATERIALS. THE CONTRACTOR IS RESPONSIBLE, FURTHERMORE, FOR PROTECTING ALL WORKERS FROM BEING EXPOSED TO DANGEROUS MATERIALS. SO, BECAUSE THE BP-9-SP MACHINE HAS NOT BEEN DESIGNED TO REMOVE, CLEAN, PROFILE, OR ALTER ANY SURFACE COATED WITH OR OTHERWISE CONTAMINATED BY DANGEROUS MATERIALS, BLASTPRO MANUFACTURING, INC. EXPRESSLY DISCLAIMS ANY LIABILITY FOR INJURY, ILLNESS, DEATH, OR DAMAGE THAT MIGHT OCCUR OR RESULT FROM SUCH IMPROPER USE.

- Work area has been blocked off to pedestrians, unprotected personnel, and untrained personnel. In the event pedestrians, unprotected personnel, or untrained personnel enter the work area, blasting operations are to be stopped immediately.
- Fire extinguishers are nearby. Also, take note of the location and the contact information of fire departments close to the work site.
- All glass and equipment, including vehicles, are protected from steel shot. This can be done by loosely hanging a sheet of visqueen or other protective material in front of the glass or equipment in a curtain-like fashion. The importance of protecting glass and equipment from steel shot cannot be overemphasized.
- Plug or cover all floor drains to prevent steel shot from falling into the drains.
- This equipment is only to be used for commercial purposes. This equipment is only to be operated by professional, trained, and competent operators.
- The operator must be aware of their surroundings and use common sense. **THE OPERATOR IS NOT TO OPERATE THE EQUIPMENT IF HE OR SHE IS TIRED, DISTRACTED, OR UNDER THE INFLUENCE OF DRUGS, ALCOHOL, OR MEDICATION THAT DECREASE AWARENESS!**

Safety—Start Up Procedures

After performing the site assessment safety procedures listed above, bring the BP-9-SP to the work area and perform the following procedures:

- Verify that personnel are competent and that they have read and understood the safety information in this manual. Staff must also be familiar with how to operate the machine and with all of its components. Make certain that all personnel follow all safety instructions and programs required by their company and by the worksite.
- Before putting the BP-9-SP in operation, make certain that the belt guards are in good condition.
- Inspect the BP-9-SP and dust collector for damage, tears, or other signs of wear.
- Verify that all fittings and hoses are tight.
- Inspect the dust collector. Verify that the dust bin is empty, filters are clean and clear of debris, and motors and fans are in working order.

Note: The dust collector must be emptied at the end of each job.

- Make certain that the shot valve control lever is closed except when the machine is actually in operation.
- Inspect all electrical cords on the BP-9-SP for damage, tears, or other signs of wear. If electrical cords are damaged, then do not attempt to perform blasting operations until cords have been repaired or replaced.
- Inspect the duct hose leading from the BP-9-SP to the dust collector. Make sure hose is free of debris, hose is not cracked and that holes do not exist. If necessary replace hose.
- Make certain that all screws and other fasteners are tight.
- Check the shot storage hopper, the feed spout, and the blast wheel for foreign bodies and remove them if present.
- Check the blast wheel blades, control cage, liners, and magnets for damages and wear. Wear grooves are acceptable until 50% of blade thickness has been worn away. When blade thickness has been worn away by more than 50%, replace all blades.
- Check the front, side, and rear seal system and brush seals for excessive wear.
- Check the tightness of the hose connections and the condition of the hose to the filter.
- Check the electrical connections for dirt and foreign body deposits.
- Verify that the electrical motors are free of dirt and other contaminants.
- Check the level of shot in the storage hopper. Refill hopper if necessary.
- Verify that the main power cable and the dust hose are free of damage. Replace or repair all damaged parts before putting the machine into operation.
- Check to confirm that all machine parts are assembled safely and correctly.

Note: It is recommended to have original spare parts and wear parts on hand. It is imperative that the machine receive special attention and regular maintenance in order to function properly and to operate safely.

- Connect the blast cleaning machine and the filter unit with the dust hose. Use hose clamps at the connections.
- Connect the supply cable of the blast cleaning machine with filter unit. Connect the electrical cable of the filter unit with the site supply.
- Make certain that the side seals are positioned correctly.

- Check that the filter dust container has been emptied.
- Always blast in a straight line away from the dust collector. Blasting in a straight line will produce the most uniform results. **NEVER RUN OVER ANYTHING WITH THE BP-9-SP! RUNNING OVER AN EXTENSION CORD, AIR LINES, REBAR EXPANSION JOINTS, OPENINGS IN FLOOR, DRAINS, ETC. WITH THE BP-9-SP CAN RESULT IN SERIOUS INJURY TO THE OPERATOR AND/OR DAMAGE TO THE EQUIPMENT!**
- Make certain to keep hands away from all moving parts once the machine is in operation.
- Make certain to never stand next to the blast housing while the BP-9-SP is in operation as blade failure could result in serious injury.
- Make certain that the shot hopper door is closed while the machine is in operation as the BP-9-SP throws shot which could present a serious danger if the shot hopper door is not properly closed.
- Make certain that the blast seals of the BP-9-SP are not worn out. As these seals provide the suction that is required by the machine, they will become dislodged if they become worn out. This will then result in shot being discharged from the machine. It is consequently recommended that the operator make absolutely certain that the blast seals are in good working condition before putting the BP-9-SP into operation.
- In the unlikely event of a failure, turn main power switch to the OFF position and make certain that the BP-9-SP and the dust collector have been disconnected from all power sources.

Note: If the BP-9-SP shot blasting machine is operated using a generator as the power source, the generator must be operated in accordance with the current VDE directives (this applies to the protective earth conductor in particular) in order to ensure that all safety devices are functioning and to eliminate possible damage to electrical components.

Safety — Operation Procedures

When operating the BP-9-SP, respect the following safety procedures:

- The BP-9-SP shall not be put into use unless it is attached to an appropriate exhaust hose and dust collector.
- **NEVER OPERATE THE MACHINE WHILE THE ELECTRICAL PANEL DOOR IS OPEN!**
- **SUPPORT PERSONNEL MUST KEEP A SAFE DISTANCE FROM THE MACHINE WHILE IT IS IN OPERATION! DO NOT STAND IN FRONT OF THE MACHINE WHILE IT IS IN OPERATION!**
- Since the speed of the machine determines the depth of its cut, it is advised that the operator run a test pattern. Failure to run a test pattern could result in the machine gouging the floor.
- The blast pattern needs to be inspected by the operator at least every ten feet as variation in concrete means that the concrete or the coated surface may be softer in some areas than it is in others.

- Whenever the dust collector becomes full, it must be emptied. Failure to empty the dust collector could result in the machine losing its suction to the floor. If this happens, then all of the shot will fall out of the shot hopper.
- Never switch off or remove the exhaust and ventilation devices when the machine is in operation.
- **A SECOND PERSON MUST BE PRESENT SO AS TO PULL OUT THE MACHINE'S PLUG IN AN EMERGENCY! THE WORK AREA MUST THEN BE SEALED OFF USING A RED AND WHITE SAFETY CHAIN AND A DANGER SIGN! USE A TOOL THAT IS INSULATED AGAINST VOLTAGES!**
- **IF AN ERROR OCCURS WHILE THE MACHINE IS IN OPERATION, IT MUST BE SHUT DOWN IMMEDIATELY! THE CAUSE OF THE ERROR MUST BE ESTABLISHED IMMEDIATELY!**
- **IF CABLES BECOME LOOSE OR SCORCHED, THE MACHINE MUST BE SHUT DOWN IMMEDIATELY!**

Safety — Shut Down Procedures

When shutting down the BP-9-SP, always perform the following safety procedures:

- Shut off the shot supply by pulling the shot valve handle backwards.
- Advance the machine until you are sure that no deep holes are being blasted into the surface.
- Turn off the breakers to the BP-9-110V and to the dust collector.
- Turn off the BP-9-SP as well as the dust collector and disconnect both from all power sources.
- Empty all dust from the dust collector. **WHEN REMOVING DUST FROM DUST COLLECTOR, ALWAYS WEAR A PARTICLE MASK. CONCRETE DUST MAY CONTAIN PARTICLES WHICH ARE EXTREMELY HAZARDOUS! THESE PARTICLES SHOULD NEVER BE INHALED!**
- Empty all shot from the shot hopper on the BP-9-SP. Shot should never be left in BP-9-SP after work is performed. Never move or transport BP-9-SP with shot in the shot hopper as this may result in damage to the equipment.
- Make certain that all dust has been removed from the dust hopper. Dust left in the dust hopper has the potential to catch on fire and/or explode without notice.
- **AFTER COMPLETING WORK, CLEAN ALL STRAY SHOT FROM WORK AREA. SHOT CAN BE CLEANED WITH A MAGNETIC BROOM OR WITH A SHOP VACUUM. NEVER LEAVE STRAY SHOT IN WORK AREA AS SHOT REPRESENTS A SLIP-AND-FALL HAZARD! STEPPING AND FALLING ON STEEL SHOT CAN RESULT IN SERIOUS INJURY OR EVEN DEATH!**

Safety — Maintenance Procedures

When performing maintenance on the BP-9-SP, make certain that the following safety procedures are followed:

- Verify that the BP-9-SP and the dust collector are not in operation. Attempting to perform maintenance operations on the BP-9-SP and/or the dust collector while they are in operation can lead to serious injury or death.
- Make certain that the BP-9-SP is in the Safety off position (valve is closed, blast machine is switched off, dust collector is switched off, all drives are at a standstill, and main plugs have been pulled).
- Never connect or disconnect power cables when voltage is present or while under load.
- Make sure that the BP-9-SP is on a level and stable surface.
- Allow the blast wheel to stop completely.
- Verify that all moveable parts of the BP-9-SP are completely still and secured against accidental movement.
- Make certain that all maintenance personnel are wearing lint-free cleaning cloths.
- Avoid contact with rotating motor parts, drives, or driven components.
- If repairing the underside of the BP-9-SP, then be certain to use jack stands. Never work under equipment that is not properly blocked.
- All repairs to electrical components, including wiring, should be performed by a licensed electrician.
- **FAILURE TO REPLACE LOOSE OR DAMAGED PARTS COULD CAUSE DAMAGE TO THE EQUIPMENT AND/OR SERIOUS INJURY OR DEATH TO THE OPERATOR!**
- **ALL REPLACEMENT ELECTRICAL COMPONENTS ARE TO BE IDENTICAL TO THE COMPONENTS ORIGINALLY SUPPLIED WITH THE BP-9-SP. SUBSTITUTION OF THESE PARTS WITH OTHER ELECTRICAL PARTS CAN RESULT IN DAMAGE TO THE BP-9-SP AND INJURY TO THOSE NEARBY.**
- All replacement electrical components are adjusted correctly.
- Make certain that electrical equipment is inspected regularly.
- All other repairs must be completed by competent, qualified personnel.
- **FAILURE TO REPLACE LOOSE OR DAMAGED PARTS COULD CAUSE DAMAGE TO THE EQUIPMENT AND/OR SERIOUS INJURY OR DEATH TO THE OPERATOR!**
- Verify that aggressive cleaning products are not used.
- **MAKE CERTAIN TO NEVER WELD, FLAME CUT/TORCH, OR PERFORM ANY GRINDINGWORK ON THE BP-9-SP WITHOUT WRITTEN AUTHORIZATION FROM THE MANUFACTURER!**
- Make certain that process materials and replaced parts are disposed of safely and in an environmentally-appropriate manner.
- After performing maintenance operations on the BP-9-SP, verify that all safety labels, guards, control panels, housings, lids, seals, casters, and other parts that have been replaced are secure.
- Remove and properly dispose of all maintenance refuse such as shot from the work area.

Check List

The tasks listed on this check list must be completed before the BP-9-SP can be put into operation. Completing these tasks is essential in order to increase the efficiency and safety of the BP-9-SP.

- Blades..... Check for excessive wear.
- Blast Wheel..... Check for balance and excessive wear.
- Top Liner Check for excessive wear.
- Lower Liner Check for excessive wear.
- Blast Wheel Bearings..... Check set screws and grease
(Lucas Red 'N' Tacky #2:
High Speed, High Temp).
- Shot Valve..... Make sure shot is not leaking from shot hopper.
- FiltersMake sure filters are secure and not clogged, ripped, or wet.
- Wheels..... Check for excessive wear.
- Belts Check quality and tension.
- Dust Collector Latches..... Make sure latch firmly secures door.

Operating Instructions—Start Up

1. Verify that all personnel are competent and that they have read and understood the safety information in this manual. All personnel must follow all safety instructions and programs required by their company and the worksite.
2. Verify that the BP-9-SP is on a level, clean, debris-free and dry surface. Connect the hose from the dust collector to the BP-9-SP. Verify that all clamps are secure.
3. Verify that the dust bin in the dust collector is empty and that the hose is free of debris.
Note: The dust bin should be emptied whenever it becomes full as well as after each and every job.
4. Verify that shot hopper contains no shot.
Note: The shot hopper should be emptied whenever it becomes full as well as after each and every job.
5. Make certain that the feed spout, seals, liners, control cage, blast wheel, and hopper parts are in good working condition.
6. Make certain that all electrical components are free of damage or excessive wear.
7. Make certain that the exhaust hose has no holes, leaks, deformities, or restrictions present.
8. Verify that the switch on the control panel of the BP-9-SP is set to the OFF position.
9. Verify that the switch on the control panel of the dust collector is set to the OFF position.
10. After confirming proper voltage with a voltmeter, insert the plug from the BP-9-SP into a 230 volt electrical outlet.
Note: Site power should never drop below 187 volts.
11. After confirming proper voltage with a voltmeter, insert the plug from the dust collector into a 230 volt electrical outlet.
Note: For the dust collector, use an outlet which is operated by a separate circuit breaker than is being used to power the BP-9-SP.
Note: Site power should never drop below 187 volts.
12. Make sure that any hardwiring or circuit breaker changes are performed by a licensed electrician.
13. Before loading the steel shot into machine, turn the switch on the BP-9-SP and the dust collector to the ON position for two minutes so as to verify that the circuit breaker will not trip.
14. Disconnect the hose from the BP-9-SP to verify that the dust collector has proper suction.
15. After verifying proper suction, reconnect the hose to the BP-9-SP.
16. Check the seals on the BP-9-SP to verify that the seals are set at the proper height. The seals should be rubbing the surface of the concrete or steel.
17. Insert drive pin.
18. Place a handful of steel shot in front of the BP-9-SP.
19. Push the BP-9-SP over the handful of steel shot. This will attach the steel shot to the magnetic seals and prevent shot from escaping from the BP-9-SP.
Note: Be certain to dispose of any shot that remains on the surface to be blasted.
20. Pour steel shot into the BP-9-SP shot hopper to the bottom of the screen.
21. Turn the switch on the BP-9-SP to the ON position, turn pot switch up to desired speed and drive the BP-9-SP forward as you push the shot valve to open the shot valve, and verify that the blast pattern is uniform. If blast pattern is uniform, then proceed to step

- #23. If blast pattern is not uniform, then release the shot valve handle to close the shot valve, turn the switch on the BP-9-SP to the OFF position, and proceed to step #21.
22. Adjust the control cage (if necessary, refer to Setting the Blast Pattern section below).
23. Turn the switch on the BP-9-SP to the ON position, open the shot valve, squeeze the shot valve handle and push the BP-9-SP. Be sure to verify that the blast pattern is uniform.
24. Once blast pattern is uniform, start shot blasting.
25. After approximately ten feet of shot blasting, close the abrasive valve, stop the machine, shut off blast wheel and inspect the recently blasted area.
26. If test area appears to have been blasted evenly, proceed to step #27.
27. If test area appears to have been blasted unevenly, then go to the section in this manual that addresses “Setting the Blast Pattern.” After adjusting the blast pattern to a satisfactory degree, proceed to step #27.
28. After confirming that the BP-9-SP is blasting in an even, desired pattern, begin to once again walk behind the machine to operate it in a forward direction.
- Note: Make certain to not exceed the amperage rating for the operating voltage.**
29. If blasting becomes inadequate, it may be necessary to adjust travel speed. A faster speed will produce a more shallow profile while a slower speed will produce a deeper profile.
30. Once a satisfactory profile has been obtained, continue to blast in straight lines. Blasting in straight, consistent lines gives the best results.
31. In order to clear small obstructions on the surface being cleaned, simply pull up on the steering handle.

Note: Caution must be used whenever lifting up on the steering handle. This is because such a maneuver can cause the magnetic seal between the shot and the surface to be broken. If this seal is broken, shot may escape from the machine at a very high velocity.

Setting the Blast Pattern

Setting the proper blast pattern is determined by trial and error. The importance of selecting the proper blast pattern cannot be overstated. An improper or unevenly distributed blast pattern will result in excessive blasting on either the right side or left side of the machine and will leave shadows or “track” lines in the blast pattern.

When setting the blast pattern perform the following steps:


1. Verify that the blast wheel is rotating in the direction shown on the blast housing.
2. Place a sheet of steel approximately ¼” thick under the machine and then blast with the shot valve fully open for approximately one minute.
Note: Do not move the machine during this time.
3. After blasting for one minute, shut down the machine and inspect the blast pattern. The “hot spot” should be in the center of the width blasted. The “hot spot” can be altered by rotating the control cage in small increments. Rotating the control cage in a counter-clockwise direction will move the “hot spot” to the right while rotating the control cage in a clockwise direction will move the “hot spot” to the left. If you visualize a clock, the opening of the control cage should be set at approximately 11:30 (leading edge) and 9:30 (trailing edge) on the clock (see “Proper Control Cage Setting Drawing” below). The

size of steel shot used will impact where the “hot spot” appears in the blast pattern. The operator will need to adjust the control cage based upon the size of steel shot utilized.

Note: The setting of the control cage will vary depending both on the size of shot used and on the type of surface being blasted. When altering the position of the control cage, make sure to only adjust it in small increments. Keep adjusting the control cage until the desired blast pattern has been obtained. Once the desired blast pattern has been obtained, the blast pattern should remain consistent.

Note: Four factors may affect the blast pattern. Of these, the control cage setting is the most crucial. Other factors that may also affect the blast pattern include the size of the shot being used, the wheel rotation, and the worn wheel kits. If adjusting the control cage setting does not allow the desired blast pattern to be achieved, then it is important to narrow down what is causing the problem. First, take into consideration the size of shot being used. If this does not resolve the problem, then check and, if necessary, replace the wheel rotation and the worn wheel kits.

Proper Control Cage Setting Drawing



Operating Instructions—Shut Down

1. Close the shot valve.
2. Stop the BP-9-SP forward and turn the speed control knob to zero.
3. Turn off the blast wheel.
4. Turn off the BP-9-SP.
5. Turn off the dust collector.
6. If this is only a temporary stoppage, then check the dust collector and empty it if necessary. If this stoppage is the result of being done for the day, then empty the dust collector no matter the amount of dust within it.
7. If this is only a temporary stoppage, then check the shot hopper and empty it if necessary. If this stoppage is the result of being done for the day, then empty the shot hopper no matter the amount of shot within it.
8. Make certain that the BP-9-SP is in a safe location if it is to be left at the job site. If the BP-9-SP is to be transported, then please refer to the section in this manual that addresses “Transportation.”

Operation Adjustments

The BP-9-SP can be manipulated to make blasting easier for the operator. When adjusting the blast housing height, control cage settings, extreme caution must be used. The BP-9-SP and the dust collector must be turned off and completely disconnected from all power sources. Also, all moving parts must be completely stationary. See the “Safety—Maintenance Procedures” section of this manual for further guidance on how to safely perform maintenance on the BP-9-SP.

Blast Housing Height: The bottom of the blast housing should be between 1/8” to 1/2” above the surface being cleaned. A smaller clearance can be obtained for smooth surfaces and the height may need to be higher for rough surfaces.

Control Cage Setting: See the section in this manual that covers “Setting the Blast Pattern.”

Shot Selection Recommendations:

- Cleaning scale or paint on steel: S-460
- Heavy Concrete Removal: S-460
- Rough concrete etch for coatings: S-330 to S-460
- Brush blast of smooth concrete: S-170 to S-280

Travel Speed Suggestions:

- Light blasting: 70% to 100% of full travel speed
- Heavy concrete blast: 15% to 40% of full travel speed
- Steel surface cleaning: 10% to 15% of full travel speed

Exhaust Hose Length: Twenty five feet of three inch diameter exhaust hose. Longer or shorter hoses may affect shot consumption and blasting by the BP-9-SP differently.

Transportation

When transporting the BP-9-SP shot blasting machine, it is strongly recommended that personnel act in a manner so as to reduce the potential that damage takes place as a result of using excessive force or of using incorrect loading and unloading procedures. Forklifts should never be used to transport the machine.

Note: Personnel must remove any abrasive from the machine before it is transported. Also, the machine may only be lifted by using the suspension eyelets.

Dust Collector Function

The BP-9-SP shot blasting machine is equipped with an auto pulse dust collector that helps to both separate the dust from the shot and to return clean air back into the environment.

The most fundamental part of the dust collector is referred to as the filter chamber. Air containing dust particles enters the filter chamber from the blasthead via the exhaust hose. This air then moves into the dust collector inlet connection located on the left, front side of the dust collector. Next, the air passes through a plenum and moves through filter cartridges. These filter cartridges capture the dust particles and prevent them from moving on with the air. Now dust-free, the air then passes to the clean air portion of the dust collector where it is subsequently released back into the environment by way of the silencer box.

Dust Collector Maintenance

The dust collector must be examined habitually. This is because adequate ventilation is essential for the dust collector. It is therefore vital that the following areas are routinely examined:

- Adequate ventilation is available at all times. Ventilation irregularities can have a negative effect on the efficiency of both the BP-9-SP and the dust collector. Poor ventilation results in excessive wearing of the blast wheel and liner wear.
Note: Despite conventional wisdom, shot is not the primary cause of wear and tear to shot blasting machines. In actuality, it is the dust and other contaminants produced by these machines that typically cause their parts to wear prematurely. As a result, it is essential that proper ventilation be supplied to the machine at all times by keeping the dust collector free of excessive contamination.
- The hose connections between the blasthead and the dust collector must be tight and kept in place with the use of metal clamps.
- The hose must be in good condition. Flattened spots, holes, and wear spots should be corrected without haste. Hose must be replaced if necessary.
- Filter cartridges must be kept in good, working condition.

If the dust collector is not in proper, working order, then this can have a detrimental effect on the entire system. Improper ventilation can result in inadequate abrasive cleaning which hastens blast wheel and liner wear. It is, consequentially, essential that the dust collector be well maintained. A dust collector that receives timely, regular maintenance will result in less shot contamination which will help to both reduce operating costs and increase overall effectiveness.

Filter Cartridge Removal

WARNING: BEFORE INSPECTING OR REMOVING FILTER CARTRIDGES, MAKE SURE THAT THE BP-9-SP SHOT BLASTING MACHINE IS ON A LEVEL SURFACE. ALSO, MAKE SURE THAT THE MACHINE HAS BEEN PROPERLY IMMOBILIZED. FINALLY, VERIFY THAT BP-9-SP IS IN THE OFF POSITION AND HAS BEEN DISCONNECTED FROM ALL POWER SOURCES.

Wear Parts

The BP-9-SP contains parts which are continually exposed to steel shot moving at high rates of speed. Exposure to steel shot traveling at high rates of speed and concrete dust causes these parts to deteriorate over time. As a result, the operator or maintenance personnel should inspect the BP-9-SP wear parts prior to operation and change the parts as necessary. Wear parts and inspection times, other than inspections prior to use, are listed below:

Part	When to Inspect	Evidence of Wear
Feed Spout	50 hours	Thin spots
Blast Wheel	05 hours	Blades deteriorated > 50%
Control Cage	05 hours	Deteriorated edges
Blast Wheel Hub	10 hours	Missing pins/deterioration
Liners	50-75 hours	Warping, holes, deterioration
Blast Housing	50-75 hours	Thin sections or other deteriorations
Deflector Plate	50 hours	Thin spots; wearing at welds
Separator	100 hours	Thin spots; wearing at welds; warping
Top Cover	50 hours	Inside edge erosion

Note: Parts of the BP-9-SP which should also be inspected regularly but are not exposed to steel shot are the control panel, motor, electric cords, dust collector hose, filters, and motors. If any of these components show signs of wear they should be repaired so that they are in the same working condition as when they were new. If they cannot be repaired, then they should be replaced immediately.

Maintenance

Blast Wheel Removal and Installation

When the blades on the blast wheel are deteriorated by 50% or more, then the blast wheel should be replaced. To replace the blast wheel, perform the following steps:

1. Verify that the BP-9-SP is turned off and disconnected from all power sources.
2. Remove the feed spout and the control cage.
3. Remove the four mounting nuts, flat washers, and lock washers that secure the control cage mounting assembly to the blast housing. Do not loosen any other screws on the control cage mounting assembly since they are used to set the gap between the blast wheel and the control cage. Remove the control cage mounting assembly.
4. Remove the socket head cap screw and lock washers from the blast wheel and remove the blast wheel.
5. Check the wheel hub for wear and replace if necessary.
6. Install new blast wheel using the new socket head cap screw and lock washers that are included in the wheel kit. Be sure that the new blast wheel is seated properly on the wheel hub before tightening the socket head cap screw.
7. Reinstall the control cage mounting assembly to the blast housing.
8. Install the new control cage that was included with the wheel kit. Rotate the wheel by hand to be sure that the control cage and the wheel do no touch. The initial window setting for the control cage should be between 9:30 and 11:30.
9. Reinstall the feed spout.
10. Energize the blast motor momentarily to check for good balance and proper clearance before shot blasting.
11. See the section in this manual about “Setting the Blast Pattern” before adjusting the control cage.

Note: Only blast wheels manufactured by BlastPro Manufacturing, Inc. should be used by the BP-9-SP. Other blast wheels that have not been tested by BlastPro Manufacturing, Inc. could result in damage to the equipment or injury to the operator.

Lubrication

The bearing unit that is located directly behind the blast wheel outside the blast housing must receive periodic lubrication. This unit operates at over 200° Fahrenheit and requires the use of a high temperature, lithium-based grease.

The bearing unit should receive several pumps of this high temperature, lithium-based grease at least every 50 hours. Several pumps of grease from a standard grease gun should be sufficient.

Note: The grease needs to be inserted into the grease fittings on the bearing unit. Once the unit is greased, run the blast wheel for 10-15 minutes to remove any excess grease. Be careful not to over-grease this unit.

Shot Blasting Problems & Possible Solutions

Problem: BP-9-SP will not operate.

Possible Solution: First, make sure the machine is being supplied power and that this power is within proper parameters. Second, verify that the BP-9-SP and dust collector are turned on. Third, with BP-9-SP as well as dust collector turned off and all power sources disconnected, open panel door on BP-9-SP and check the status of the Control Power Overload in each control panel. Make sure that the overload device is in the on position.

Problem: Breaker is tripping when BP-9-SP and dust collector are turned to the ON position.

Possible Solution: BP-9-SP and dust collector should be powered by separate breakers. Find electric outlets with separate breaker switches and use accordingly. Check circuit breaker sizes.

Problem: BP-9-SP is vibrating excessively.

Possible Solution #1: Check blast wheel immediately. Excessive vibration is usually caused by the blast wheel being out of balance due to it being worn or by blades being broken or chipped. Install new blast wheel kit. Failure to install new wheel kit in this instance could lead to serious damage to machine.

Possible Solution #2: If blast wheel doesn't seem to have any problems, check ventilation system. A ventilation system that requires maintenance may cause the BP-9-SP to shake excessively.

Problem: BP-9-SP is creating excessive noise.

Possible Solution #1: This problem is most likely caused by an improper alignment of the blast wheel and control cage. Check alignment of blast wheel and control cage immediately and verify that there is adequate clearance between the blast wheel and the control cage.

Possible Solution #2: If blast wheel and control cage are aligned probably but excessive noise persists, it could be that other rotating parts are coming into contact with each other. Check bearing units, belts, sheaves, motor mounting, wheel housing, and any other associated parts to be sure that they are aligned and safely secured.

Problem: BP-9-SP is taking longer to shot blast than before.

Possible Solution: It could be one of several problems. First, check to see how shot is being fed to the wheel. It is important to make sure that enough shot is getting to the wheel. Second, make sure storage hopper has enough shot within it. Third, verify that shot is not contaminated. Shot should be fairly clean and ventilation system should be working properly. Fourth, check shot feed and shot control valve. Obstructions in the shot feed or shot valve can slow down shot blasting. Fifth, check wheel impeller and control cage. Excessive wear may warrant replacing wheel kit. Sixth, investigate drive belt and make sure it has proper tension, correct alignment,

and is not worn out. Seventh, look to see if blast pattern is still consistent. If it is not, make sure that the blast wheel is sitting properly in the wheel hub. And finally, eighth, check the wheel. Make sure that the shot valve is working properly.

Problem: BP-9-SP is creating excessive wear on liners and blast housing.

Possible Solution: Adjust control cage so that the “hot spot” is centered in work area rather than on liners or housing.

Problem: BP-9-SP is dropping an excessive amount of steel shot.

Possible Solution: Verify “hot spot” is centered properly and adjust control cage as necessary. Verify seals do not have excessive wear, feed spout is aligned properly, and shot valve is closing when shot lever is released. Verify dust collector has adequate suction.

Problem: BP-9-SP will not move forward.

Possible Solution: Make certain that the drive pin has been installed. Check wiring plugs and replace any faulty components.

Problem: BP-9-SP is difficult to push or gets stuck in areas.

Possible Solution: Verify that the seals are positioned properly and that they are not too close to the floor. Raise height of seals. Pull up on steering handle to clear small obstructions on the work surface. Use extreme caution when doing so as this maneuver may cause shot to shoot out of the machine and into the work area.

Problem: BP-9-SP is not blasting properly.

Possible Solution: Slow machine down so that a deeper profile is created.

Problem: The shot is contaminated.

Possible Solution: Increase the speed of the BP-9-SP. This will reduce shot flow to the wheel. Also, check fan rotation, exhaust hose and connections, and air control gate to be sure that enough air flow is being delivered by the exhaust fan.

Problem: BP-9-SP or dust collector is emitting concrete dust.

Possible Solution: Verify there are no holes in the duct hose leading from the BP-9-SP to the dust collector. Verify filters in the dust collector are properly installed and are clean. If necessary replace filters in dust collector.

Problem: Fan motor overload trips.


Possible Solution: Attach an end cap into open port. Also, check electrical system.

BP-9-SP PARTS ILLUSTRATIONS

10MM x 1.5 x 25MM Socket head
cap screw with flat and lock washer.

#BP4595560 Blast Wheel.

#BT4900890 Blast wheel bushing.



#BT6962750 Blast wheel hub.



#BP4514760 Control cage.



BP-9-SP PARTS ILLUSTRATIONS


#BT6962770 Mount plate.

#BTP002656 Felt seal.



#BT6962770 Mount plate.

#BT6962920 Bearing Unit.



#BT6986760 Top Liner.

#BT6986740 Left Hatchet Liner.

#BT6986750 Right Hatchet Liner.

#BT6986780 Rebound Liner.




BP-9-SP PARTS ILLUSTRATIONS

#BT9697630 Front Magnet.

#BT9697170-B Front/Rear Brush.

#BT9697800 Side Magnet.

#BT6908301 Side Brush.



#BTP000001 Shot Valve Assembly.

#BT9763240 Control Cage Adapter Plate.

#BT9700120 Control Cage Clamp.

#BP4514760 Control Cage.



#BTP000736 Shot Valve Cable.

Shot valve linkage (part of #BTP000001)

